



## How To Start A Petrol Quad Bike

1. Ensure the petrol tap is in the upright position, the ignition barrel is in the ON position, and the silver lever (choke) is in the upper position.



2. Pull the pull-start-handle three or four times, this will prime the engine ready to start. Pull the pull-start out slightly ensuring it is coming out straight and not at an angle, before starting the engine. Once the pull-start is in this position with a firm grip on the handlebar, the pull-start can be gently pulled to turn the engine. Ensuring not to force the pull-start out too far, as improper usage of the pull-start will damage the unit, and is not covered by the warranty.



3. Once the engine has started, and runs for a few minutes, lower the silver lever (choke) to the lower position.

## How To Restrict The Quad Bike Speed

To limit the speed on a petrol quad bike, please locate the adjustment screw on the throttle, the tighter the screw the less the throttle will engage.

